

Programming Software

P3-PGMSW <--->

Productivity Suite is user-friendly programming software designed to allow quick and easy programming of ladder logic programs for the Productivity3000 PAC.

The online help file provides information that will help you get acquainted with the software quickly.

PC Requirements

Productivity Suite programming software works with Windows® 2000 Service Pack 4, XP Home or Professional, or Vista (32 bit only). These are the minimum system requirements:

- Personal Computer with a 333 MHz or higher processor (CPU) clock speed recommended; Intel Pentium/Celeron family or AMD K6/Athlon/Duron family, or compatible processor recommended
- SVGA 800x600 pixels resolution. (1024x768 pixels resolution recommended)
- 150MB free hard-disk space
- 128MB free RAM (512MB recommended)
- CD-ROM or DVD drive for installing software from the CD
- USB or Ethernet port for project transfer to PAC



Main window

The Main Window is displayed when the program opens. It is divided into Menus, Toolbars, and Windows that work together to make project development as simple as possible.

Programming Cable


You will need a standard USB or Ethernet cable for programming, depending on whether you use the USB or Ethernet programming port on the P3-550 CPU.

We recommend using a USB programming cable; just plug it in and it works.

We sell these A-to-B USB cables:

- USB-CBL-AB3 (3 ft.)
- USB-CBL-AB6 (6 ft.)
- USB-CBL-AB10 (10 ft.)
- USB-CBL-AB15 (15 ft.)

Application Tool Panel



Task Management Panel

Ladder Editor Window

Instruction Panel Window